

see Conte and Mackay, Chapter 9
Wille, Chapter 5
Wiedemann, § 2.2

RF Cavities

Maxwell's equations in vacuum region:

$$\nabla \cdot \vec{E} = 0$$

$$\nabla \times \vec{E} = -\frac{\partial \vec{B}}{\partial t}$$

$$\nabla \times \vec{B} = \frac{1}{c^2} \frac{\partial \vec{E}}{\partial t}$$

$$\nabla \cdot \vec{B} = 0$$

Vector Identity

Maxwell Eqn to eliminate

$$\nabla \times (\nabla \times \vec{E}) = -\frac{\partial}{\partial t} \nabla \times \vec{B} \rightarrow \nabla (\nabla \cdot \vec{E}) - \nabla^2 \vec{E} = -\frac{\partial}{\partial t} \left(\frac{1}{c^2} \frac{\partial \vec{E}}{\partial t} \right)$$


$$\nabla \times (\nabla \times \vec{B}) = \frac{1}{c^2} \frac{\partial}{\partial t} \nabla \times \vec{E} \rightarrow \nabla (\nabla \cdot \vec{B}) - \nabla^2 \vec{B} = \frac{1}{c^2} \frac{\partial}{\partial t} \left(-\frac{\partial \vec{B}}{\partial t} \right)$$

$$\boxed{\begin{aligned} \nabla^2 \vec{E} - \frac{1}{c^2} \frac{\partial^2 \vec{E}}{\partial t^2} &= 0 \\ \nabla^2 \vec{B} - \frac{1}{c^2} \frac{\partial^2 \vec{B}}{\partial t^2} &= 0 \end{aligned}}$$

\vec{E}, \vec{B} satisfy Wave equations.

1st step:

We will look for EM wave solutions in a perfectly conducting, cylindrical pipe "waveguide".



$r_c =$ Radius Cylinder

Maxwell eqns give boundary conds on perfect conductor: \vec{E} : Tangential zero, \vec{B} : Normal zero

Search for a solution with z-t traveling wave form with harmonic time (t) and z dependence
* $\sim e^{-i\omega t}$ time variation, $i = \sqrt{-1}$, take Re $\{ \}$ for physical part.

$$\left. \begin{aligned} E_z &= E_z(r, \theta) \cdot e^{i(\omega t - kz)} \\ E_r &= E_r(r, \theta) \cdot e^{i(\omega t - kz)} \\ B_\theta &= B_\theta(r, \theta) \cdot e^{i(\omega t - kz)} \end{aligned} \right\} \begin{aligned} \omega &= \text{const Angular Frequency} \\ k &= \text{const Axial Wavenumber} \\ \text{Transverse Magnetic form since want longitudinal } E_z \text{ for acceleration} \end{aligned}$$

Nonzero field components, in cylindrical-polar coordinates.

Later will restrict $E_z(r=c) = 0$ to meet boundary conditions.


Field Boundary Conditions: Conducting walls

Apply Maxwell's eqns at boundary of perfect conductor

Maxwell Eqns Media

$$\begin{aligned} \nabla \cdot \vec{D} &= \rho \\ \nabla \times \vec{E} &= -\frac{\partial \vec{B}}{\partial t} \\ \nabla \times \vec{H} &= \vec{J} + \frac{\partial \vec{D}}{\partial t} \\ \nabla \cdot \vec{B} &= 0 \end{aligned}$$

Integrate over \Rightarrow limiting pill box + loop $\vec{J}, \vec{D} \rightarrow 0$



In vacuum:

$$\begin{aligned} \vec{D} &= \epsilon_0 \vec{E} \\ \vec{B} &= \mu_0 \vec{H} \end{aligned}$$

So we have for field boundary conditions in the ideal vacuum / perfect conductor interface:

$$\left. \begin{aligned} \vec{E} |_{\text{tangential}} &= 0 \\ \vec{B} |_{\text{normal}} &= 0 \end{aligned} \right\} \begin{array}{l} \text{Exclude} \\ \text{Allow} \end{array}$$


$$\left. \begin{aligned} \vec{E} |_{\text{normal}} &\text{ allowed} \\ \vec{B} |_{\text{tangential}} &\text{ allowed} \end{aligned} \right\}$$

\Rightarrow surface charge Σ adjusts to shield conductor
 \Rightarrow surface current \vec{K} adjusts to shield conductor


Boundary Conds

$$\begin{aligned} \hat{n} \cdot \vec{D} &= \Sigma \\ \hat{n} \times \vec{E} &= 0 \\ \hat{n} \times \vec{H} &= \vec{K} \\ \hat{n} \cdot \vec{B} &= 0 \end{aligned}$$

Σ = Surface Charge Density
 \vec{K} = Surface Current Density



Implications in Pipe Segment: E_z, E_θ, B_θ allowed



B_θ No restrictions

Examine only E_z in $(\nabla^2 - \frac{1}{c^2} \frac{\partial^2}{\partial t^2}) E = 0$

$\nabla^2 = \frac{1}{r^2} \frac{\partial}{\partial r} (r^2 \frac{\partial}{\partial r}) + \frac{1}{r^2} \frac{\partial^2}{\partial \theta^2}$

$\nabla^2 E_z + (\omega^2 - k^2) E_z = 0$

Look for a solution with harmonic azimuthal variation

$E_z \sim \cos(n\theta)$ choose $\theta=0$ reference to make true.

$\frac{\partial^2}{\partial r^2} E_z + \frac{1}{r} \frac{\partial}{\partial r} E_z + (k_c^2 - \frac{n^2}{r^2}) E_z = 0$
 $k_c^2 \equiv \frac{\omega^2}{c^2} - k^2$

Bessel Function Equation.

Recognizing this as Bessel's equation, the general solution is

$E_z = C_1 J_n(k_c r) + C_2 Y_n(k_c r)$ C_1, C_2 constants

$J_n(x)$ = Ordinary n th order Bessel function of 1st kind
 $Y_n(x)$ = Ordinary n th order Bessel function of 2nd kind

$\lim_{r \rightarrow 0} Y_n(k_c r) \rightarrow \infty \Rightarrow C_2 = 0$ for finite (physical) E-Field near $r=0$.

Putting back in variation in θ, z, t , we have:

$E_z = E_0 J_n(k_c r) \cos(n\theta) e^{i(\omega t - k z)}$
 $E_0 = \text{const. (complex)}$

We can now substitute this back in the Maxwell's eqns to find the form of B_θ and E_r consistent. But first, simplify by further restricting to $n=0$ since for accelerating particles we prefer no azimuthal variation.

Maxwell Eqns

$$\frac{\partial}{\partial z} = -ik, \quad \frac{\partial}{\partial t} = i\omega$$

$$\nabla \cdot \vec{E} = 0: \quad \frac{1}{r} \frac{\partial}{\partial r}(r E_r) - ik E_z = 0 \quad (1)$$

$$\nabla \times \vec{B} = \frac{1}{c} \frac{\partial \vec{E}}{\partial t} \quad \hat{r}: ik B_\theta = \frac{\omega}{c^2} E_r \quad (2)$$

$$\hat{z}: \frac{1}{r} \frac{\partial}{\partial r}(r B_\theta) = \frac{i\omega}{c^2} E_z \quad (3)$$

$$\nabla \times \vec{E} = -\frac{\partial \vec{B}}{\partial t} \quad \hat{\theta}: \frac{\partial E_z}{\partial r} - ik E_r = -i\omega B_\theta \quad (4)$$

$\nabla \cdot \vec{B} = 0$ satisfied, \checkmark
by symmetry

$$E_r = \frac{-i/k \frac{\partial E_z}{\partial r}}{1 - \omega^2/c^2 k^2} = \frac{ik \frac{\partial E_z}{\partial r}}{k_c^2}$$

$$B_\theta = \frac{-i\omega k_c^2}{1 - \omega^2/c^2 k^2} \frac{\partial E_z}{\partial r} = \frac{i\omega k_c^2 \frac{\partial E_z}{\partial r}}{k_c^2}$$

$$k_c^2 = \omega^2/c^2 - k^2$$

Then we have:

$$E_z = E_0 J_0(k_c r) e^{i(\omega t - k_z z)}$$

$$E_r = E_r(r) e^{i(\omega t - k_z z)}$$

$$B_\theta = B_\theta(r) e^{i(\omega t - k_z z)}$$

$E_r(r), B_\theta(r)$ must be calculated consistent with E_z form

From 2) $B_\theta = \frac{\omega}{c^2 k} E_r$

\checkmark sub B_θ above

From 4) $\frac{\partial E_z}{\partial r} = ik E_r - i\omega B_\theta = \left(ik - \frac{i\omega^2}{c^2 k} \right) E_r \Rightarrow$

$$k_c^2 = \omega^2/c^2 - k^2 \quad e^{i(\omega t - k_z z)}$$

Using $J_0'(x) = -J_1(x); \quad \frac{\partial E_z}{\partial r} = -E_0 k_c J_1(k_c r) e^{i(\omega t - k_z z)}$

$$E_z = E_0 J_0(k_c r) e^{i(\omega t - k_z z)}$$

$$E_r = -i E_0 k_c \frac{J_1(k_c r)}{k_c} e^{i(\omega t - k_z z)}$$

$$B_\theta = -i \frac{E_0 \omega}{c^2 k_c} J_1(k_c r) e^{i(\omega t - k_z z)}$$


$$k_c^2 = \omega^2/c^2 - k^2 \Rightarrow E_r(r) = -i E_0 k_c \frac{J_1(k_c r)}{k_c}$$

$$\Rightarrow B_\theta(r) = -i \frac{E_0 \omega}{c^2 k_c} J_1(k_c r)$$

Finally, need $E_z(r=r_c) = 0$ to satisfy tangential $\vec{E} = 0$ on conducting boundary

$$\Rightarrow J_0(k_c r_c) = 0 \Rightarrow k_c r_c = X_{0j} \quad j=1, 2, 3, \dots \text{ zero of } J_0(X_{0j}) = 0$$

Bessel function:



Wave phase velocity

$$\psi = \omega t - k z = \text{const}$$

$$\dot{\psi} = \omega - k \dot{z} = 0 \Rightarrow \dot{z} = \frac{\omega}{k}$$

$$x_{01} \approx 2.405$$


1st zero.

Choose 1st zero to try and get flat field near $r \approx 0$.

* Higher zeros increases argument of J_0

$$\Rightarrow k c = \sqrt{\omega^2 - k^2 c^2} \quad c = x_{01}$$

$$\omega^2 = \omega_c^2 + k^2 c^2 \quad ; \quad \omega_c \equiv \frac{x_{01} c}{r_c} \quad \text{cutoff freq}$$



use D.R. above

$$v_{\text{phase}} = \frac{\omega}{k} = \frac{\omega c}{\sqrt{\omega^2 - \omega_c^2}} > c \quad \omega > \omega_c$$

$v_{\text{phase}} = \frac{c}{\sqrt{1 - \omega_c^2/\omega^2}} > c$ Cannot maintain resonance with particle

Note energy propagation speed at group velocity $\omega = (\omega_c^2 + k^2 c^2)^{1/2}$

$$v_{\text{group}} = \frac{d\omega}{dk} = \frac{d \sqrt{\omega_c^2 + k^2 c^2}}{dk} = \frac{c^2}{\omega k} = \frac{c^2}{\omega \frac{\omega}{c}} = c \sqrt{1 - \omega_c^2/\omega^2} < c$$

* $v_{\text{group}} < c$ as must be case for physical energy transmission.

Note: $v_{\text{group}} \cdot v_{\text{phase}} = c^2 = \text{const.}$

D.R

$$\omega = \sqrt{\omega_c^2 + k^2 c^2}$$

$$\frac{d\omega}{dk} = \frac{d \sqrt{\omega_c^2 + k^2 c^2}}{dk}$$

Cylindrical Waveguide TM_{01} Modes




Fig. 5.2 Cylindrical waveguide with TM_{01} wave.

Nonzero Fields:

$$E_z = E_0 J_0(k_c r) e^{i(\omega t - k_z z)}$$

$$E_r = -i E_0 \frac{k_z}{k_c} J_1(k_c r) e^{i(\omega t - k_z z)}$$

$$B_\theta = -i \frac{E_0 \omega}{c^2 k_c} J_1(k_c r) e^{i(\omega t - k_z z)}$$

Nomenclature:

$TM =$ Transverse Magnetic
(Longitudinal E_z)

$TM_{N\theta N_r}$

$N_\theta =$ azimuthal θ -harmonic $E_z = 0 \Rightarrow$ None

$N_r =$ Number radial zeros $E_z = 1 \Rightarrow$ One at $r=a$
(min needed for BC, with nonzero sol.)

TM_{01} Mode

// Side Point: Traveling wave accelerator works by adding disks to waveguide to slow down EM wave phase velocity to maintain particle resonance!





Fig. 2.8. Disk loaded accelerating structure for an electron linear accelerator (schematic) Wiedemann





Irises give partial reflections allowing loss free propagation only at RF wavelengths with integer multiples of the iris separation distance d .

This method is commonly used in e^- accelerators. See Wangler for details.

- * water loaded waveguide behaves like (weakly) coupled cavities.
- * Treatment analogous to methods used in condensed matter theory to study X-ray scattering in periodic lattices of atoms; Floquet Theory

So what do we do in our case? Make resonant cavity.

- * Add conducting walls at $z=0$, $z=l$
- * Superimpose forward and backward waves in cavity to meet boundary conditions and setup standing wave.
- * Time phasing of particles traversing cavity to gain energy and focus.
 - Use formulation developed in earlier notes.



Recall: Hole in ends for beam & energy's E & B fields.

Wiedemann

For cavity: Superimpose waves!

$$E_z = \frac{E_0 J_0(kr)}{2} e^{i(\omega t - kz)}$$

Forward Wave (1/2 Amp)

$$e^{i(\omega t + kz)}$$

$$+ \frac{E_0 J_0(kr)}{2} e^{i(\omega t + kz)}$$

Reflected Backward Wave (1/2 Amp)

$$E_z = \frac{E_0 J_0(kr)}{2} e^{i\omega t} + e^{-ikz} = 2 \cos(kz)$$

So far

\Rightarrow

$$E_z = \frac{E_0 J_0(kr)}{2} \cos(kz) e^{i\omega t} \approx E_0 \text{ Amplitude (Complex)}$$

k will need to be fixed to satisfy end-plate boundary conditions, see next pg.

E_r

$$E_r = -\frac{\tilde{V}_0}{Z} \frac{k}{kc} J_1(kcr) e^{i(\omega t - kz)}$$

Forward Wave
(1/2 Amp)

$$E_r = -\frac{i\tilde{V}_0 k}{Z kc} J_1(kcr) e^{i(\omega t - kz)} + \frac{\tilde{V}_0 k}{Z kc} J_1(kcr) e^{i(\omega t + kz)}$$

Reflected Backward Wave (k → -k)
(1/2 Amp)

$$E_r [e^{ikz} - e^{-ikz}] = 2i \sin(kz) e^{i\omega t} = -2 \sin(kz)$$

$$E_r = -\frac{\tilde{V}_0 k}{Z kc} J_1(kcr) \sin(kz) e^{i\omega t}$$

To meet end-plate boundary conditions $E_r|_{z=\pm l/2} = 0$

$$\sin(kz) \Big|_{z=\pm l/2} = 0 \Rightarrow \frac{kl}{2} = n\pi \quad n = 0, 1, 2, \dots$$

$$B_0 = -\frac{i\tilde{V}_0 \omega}{Z c^2 k} J_1(kcr) e^{i(\omega t - kz)}$$

B₀

$$B_0 = -\frac{i\tilde{V}_0 \omega}{Z c^2 k} J_1(kcr) e^{i(\omega t - kz)}$$

Forward Wave
(1/2 Amp)

$$B_0 = -\frac{i\tilde{V}_0 \omega}{Z c^2 k} J_1(kcr) e^{i(\omega t + kz)}$$

Reflected Backward Wave (k → -k)
(1/2 Amp)

$$e^{ikz} + e^{-ikz} = 2 \cos(kz)$$

No issues meeting boundary conditions at end-plates

$$B_0 = -\frac{i\tilde{V}_0 \omega}{Z c^2 k} J_1(kcr) \cos(kz) e^{i\omega t}$$

$$E_r = -\frac{i\tilde{V}_0 k}{Z kc} J_1(kcr) e^{i(\omega t - kz)}$$

$$k = \pm kc$$

$$V_0 = \frac{V_0}{2}$$

$$k_c^2 = \omega^2 / c^2 - k^2$$


For the pill-box cavity, due to E_z boundary condition

$$k = \frac{2N_z \pi}{l} \quad N_z = 0, 1, 2, 3$$

Inserting in the previous dispersion relation

$$\omega^2 = \omega_c^2 + k^2 c^2 = \omega_c^2 + \left(\frac{2N_z \pi c}{l} \right)^2$$

$$\omega_c \equiv \frac{\omega_0 c}{r_c}$$



Only discrete values k now allowed, for standing wave.

Choose the simplest possible solution

$$N_z = 0 \Rightarrow k = 0$$

Also gives no z -variation in E_z , which is desirable for simple gap dynamics.

Label (Nomenclature) $TM_{00} N_z \Rightarrow TM_{010}$ mode

$$\begin{aligned} E_z &= E_0 J_0(kc r) e^{i \omega t} \\ E_r &= 0 \\ B_\theta &= -i \frac{E_0 c}{\omega r} J_1(kc r) e^{i \omega t} \end{aligned}$$

$$\begin{aligned} \omega &= \omega_c = \frac{\omega_0 c}{r_c} ; k = \frac{\omega c}{c} = \frac{\omega}{c} \\ \frac{\omega}{c k} &= 1 = \frac{\omega_0}{\omega} \end{aligned}$$

\Rightarrow

$$E_z = E_0 J_0\left(\frac{x_0 r}{r_c}\right) e^{i\omega t}$$

$$E_r = 0$$

$$B_\theta = \frac{i E_0}{c} J_1\left(\frac{x_0 r}{r_c}\right) e^{i\omega t}$$

$$\tilde{E}_0 = E_0 e^{i\phi}$$

$$E_0 = \text{Amp. (Real)}$$

$$\phi = \text{Phase (Real)}$$

and take the fields to be given by the Real part of the complex expression:

$$\text{Re}[\tilde{E}_0 e^{i\omega t}] = \text{Re}[E_0 e^{i(\omega t + \phi)}] = E_0 \cos(\omega t + \phi)$$

$$\text{Re}[i\tilde{E}_0 e^{i\omega t}] = \text{Re}[i E_0 e^{i(\omega t + \phi)}] = -E_0 \sin(\omega t + \phi)$$

$$E_z = E_0 J_0\left(\frac{x_0 r}{r_c}\right) \cos(\omega t + \phi)$$

$$E_r = 0$$

$$B_\theta = \frac{-E_0}{c} J_1\left(\frac{x_0 r}{r_c}\right) \sin(\omega t + \phi)$$


Giving TM₀₁₀ cavity fields

Comments:

- * All other field terms zero. $E_r = 0$ due to $k=0$
- * Finite beam aperture at ends will allow $E_r \neq 0$ for this mode.

Used phase choices for previous convention ($t=0$ at $z=0$ center of cavity)

Used $kc = \omega$ for $k=0$ in B_θ + reflection terms with consistent phase choices



* Beam will only fill a small fraction of $r_c \Rightarrow kc r/c \ll 1$

$J_0(kr) \approx 1$ Nearly uniform E_z

$J_1(kr) \approx \frac{kr}{2}$; $B_\theta \propto r \Rightarrow$ Linear focus optic. (usually limited impact)

Reminder: In RF detunes analysis: $E_z(r,z) \approx \text{const}$ Near $r=0$

$B_\theta(r,z) \propto r$ This verifies!

Note:

Max B_θ at $k_e r = 1.891$

© End-Plates

Max $E_z = E_0$ at $r = 0$

where $J_0(0) = 1$

$$\text{Therefore: } \frac{CB_{\text{Max}}}{E_{\text{Max}}} = \frac{J_1(1.891)}{J_0(0)} = \frac{0.5819}{1} = 0.5819$$

This number can have implications for the cavity field stress/breakdown.

$E_{\text{Max}} = E_0$ as large as possible for strong acceleration.

However, larger E_{Max} can trigger breakdown issues and larger

$E_{\text{Max}} \Rightarrow$ larger B_{Max} (on cavity ends) which can also induce

a quench for superconducting cavities. Realistic cavities shaped

to try to limit these issues. \Rightarrow

Elliptical Cavities

for Superconducting RF (SRF) applications.

Pinbox cavity resonant frequency:

$$\omega = 2\pi f = \omega_c = \frac{\lambda_0 c}{l}$$

$$\lambda_0 \approx 2.405$$

$$f = \frac{2.405 c}{2\pi l}$$

Cavity Frequency

Some numbers:

Cavity freq f	Cavity Diameter $2lc$
1 MHz	240 m
10 MHz	24 m
50 MHz	5 m
100 MHz	2.5 m
500 MHz	45.9 cm
1 GHz	25 cm
3 GHz	8 cm

$$2lc = \frac{2.405c}{f}$$

Higher frequencies desired to limit size of cavities and control cost.

DORIS Storage Ring Cavity
German Electron Synchrotron
Lab DESY





Fig. 5.3 Example of a single-cell cavity. It is chosen to have the dimensions $D = 462$ mm and $l = 276$ mm used in the accelerating structure developed for the storage ring DORIS, designed for a resonant frequency of 500 MHz.

Cavities must be connected to an RF source such as a klystron. Typical connection sketched below.

- Waveguide carries TE₁₀ mode from klystron.
- Waveguide terminated near RF cavity.
- Coaxial cable pickup ~ λ/4 from waveguide termination (~ E max location)
- Connections shaped to inhibit reflections/losses.
- Ceramic window separates waveguide/coaxial cable (normal pressure) from cavity (high vacuum) without impeding RF wave.
- RF wave coupled to TM₀₁₀ mode of cavity by a loop.
- + Loop gives magnetic coupling where B₀ is near max on the outer radial wall of cavity.

Many details to do optimally; Just a brief outline here. MSU RF Power Engineering course + USPAS.



Wille
 Fig. 5.4 Design of a single-cell accelerating structure using the TM₀₁₀ mode. The exact resonant frequency is adjusted using a tuning plunger. The resonator is excited by an inductive coupling loop.

A stable standing wave will exist in cavity only if the resonance condition of the TM₀₁₀ mode is precisely satisfied.

Following an identification of cavity equivalent circuit parameters, will show that

$$Q = \frac{\omega_{res}}{\Delta\omega} = \frac{R_s}{|Z|} \gg 1 \Rightarrow \Delta\omega \text{ small}$$

ω_{res} = resonant cavity ω
 $\Delta\omega$ = Frequency bandwidth for 1% power

Cavity Stored Energy: Pill box Cavity TM_{010} mode

At any given instant in time t the energy stored in an RF cavity is:

$$U = \frac{\epsilon_0}{2} \int_{\text{cavity}} E^2 d^3x + \frac{1}{2\mu_0} \int_{\text{cavity}} B^2 d^3x = \text{Stored EM Energy}$$

Field Energy Densities

$$\rho_E = \frac{\epsilon_0 E^2}{2}$$

$$\rho_M = \frac{1}{2\mu_0} B^2$$

Use Pill box cavity fields and take $\omega t + \phi = 0$; $U = \text{const}$ so can take any time.

* This choice \Rightarrow all energy in E-field.

$$E_z = E_0 J_0(k_c r) \cos(\omega t + \phi) = E_0 J_0(k_c r)$$

$$B_\theta = -\frac{E_0}{c} J_1(k_c r) \sin(\omega t + \phi) = 0$$

and:

$$U = \frac{\epsilon_0}{2} \int_{\text{cavity}} E_z^2 d^3x = \frac{\epsilon_0 (2\pi) E_0^2}{2} \int_0^c [J_0(k_c r)]^2 r dr$$

Using integral tables:

$$\int_0^1 t J_n(x_{01} t) J_n(x_{01} t) dt = \frac{1}{2} [J_n(x_{01})]^2$$

$$\int_0^1 t J_0(x_{01} t)^2 dt = \frac{1}{2} [J_0'(x_{01})]^2 = \frac{1}{2} [J_1(x_{01})]^2$$

We have

$$\int_0^c [J_0(\frac{x_{01} r}{c})]^2 r dr = c^2 \int_0^1 [J_0(x_{01} t)]^2 t dt = \frac{c^2}{2} [J_1(x_{01})]^2$$

Numerically:

$$U = \frac{\epsilon_0 E_0^2}{2} \pi c^2 l [J_1(x_{01})]^2$$

$$U \approx 0.423 \epsilon_0 E_0^2 c^2 l$$

$$J_1(x_{01}) \approx J_1(2.405) \approx 0.51911$$

$$\frac{\pi [J_1(x_{01})]^2}{2} \approx 0.423$$

$$k_c r = \frac{x_{01} r}{c}$$

$$t = r/c$$

$$k_c = \frac{x_{01}}{c}$$

$$\int_{\text{cavity}} d^3x = \int_0^c \int_0^{2\pi} \int_0^l dr r dz d\theta = \pi \int_0^c dr \int_0^l dz = \pi r_c l$$

$\int_{\text{cavity}} dz = l = \text{length cavity}$

$\int_{\text{cavity}} d\theta = 2\pi = \text{Angular Range.}$

$$J_0'(t) = -J_1(t)$$

Ref: Pick favorite EM Book.

Cavity Dissipation: Pillbox Cavity

No perfect conductors exist, but conductivity can be high:

Copper $\frac{1}{\delta} \approx 1.7 \times 10^{-9} \Omega \cdot m$

For a good but imperfect conductor, the fields penetrate the conductor in a thin surface layer where they fall off rapidly beyond a "skin depth" δ for fields varying at harmonic frequency ω :

$$\text{Skin Depth } \delta = \sqrt{\frac{2}{\sigma \mu \omega}}$$

Copper @ 100 MHz
 $\Rightarrow \delta \approx 10^{-6} m = 1 \mu m$

Because of skin depth AC and DC resistances are not equal.

$$\text{RF Surface Resistance } R_{surf} = \frac{1}{\sigma \delta} = \sqrt{\frac{\mu \omega}{2 \sigma}}$$

$$\propto \omega^{1/2} \sim [\text{RF frequency}]^{1/2}$$

AC and DC resistance varies.
 Copper @ 100 MHz
 $R_{surf} \sim \text{milli-ohm}$.

Electromagnetic theory texts show that the time averaged power loss to the walls over the RF cycle for a harmonic varying fields:

$$\langle P_{loss} \rangle_{RF} = \frac{1}{T_{RF}} \int_0^{T_{RF}} P_{loss} dt = \frac{R_{surf}}{2} \int_{\text{Cavity Surface}} |\vec{H}_t|^2 ds$$

$P_{loss} = \text{Instantaneous lost Power}$

$\vec{H}_t = \hat{n} \times \vec{H} = \text{Tangential Component } \vec{H} \text{ at conductor. } \hat{n} = \text{normal conductor}$

$\sim e^{-i\omega t}$ vary


Interpretation: $H_t \rightarrow$ surface current.
 Integrate loss over cavity surface.

Apply this loss formula to the RF pillbox cavity

$$\langle P_{loss} \rangle_{TA} = \frac{R_{surf}}{2} \int |\vec{H}_t|^2 ds$$

$$B_0 = \mu_0 H_0 = -\frac{E_0}{c} J_1(kr) e^{i\omega t} \quad k c = \frac{\omega}{c}$$

Will have surface contributions



① ends $|H_z| = \frac{E_0}{\rho_{0c}} J_1\left(\frac{x_{01} r}{r_c}\right)$; Amplitudes

③ Outer Pipe $|H_z| = \frac{E_0}{\rho_{0c}} J_1(x_{01})$
cylinder circumference \times $\left(\frac{E_0}{\rho_{0c}}\right)^2 \int_0^{r_c} J_1^2\left(\frac{x_{01} r}{r_c}\right) r dr$ + $(2\pi r_c) \times l \times \left(\frac{E_0}{\rho_{0c}}\right)^2 [J_1(x_{01})]^2$
(Field const) \times Area

$\int_0^{r_c} J_1^2\left(\frac{x_{01} r}{r_c}\right) r dr = \frac{r_c^2}{2} \int_0^1 J_1^2(x_{01} t) t dt$

But from integral tables and properties of Bessel functions

$$\int_0^1 J_1^2(x_{01} t) t dt = \frac{r_c^2}{2} \int_0^1 J_0^2(x_{01} t) t dt = \frac{r_c^2}{2} [J_1(x_{01})]^2$$

Apply prior result used for stored energy U

$$\langle P_{loss} \rangle_{TA} = \pi r_c (r_c + l) R_{surf} \cdot \left(\frac{E_0}{\rho_{0c}}\right)^2 [J_1(x_{01})]^2$$

$$\approx 0.847 r_c (r_c + l) R_{surf} \cdot \left(\frac{E_0}{\rho_{0c}}\right)^2$$

Numerically

$$\pi [J_1(x_{01})]^2 \approx 0.847$$

Typical Cavity Result

* Loss depends on surface resistance (R_{surf}), peak field (E_0), and geometric parameters (Cavity geom. specific)

* Need Low R_{surf} for low losses.

Scaling of R_{surf} :

Normal Conducting

$$R_{surf} = \sqrt{\frac{1200}{20}} \propto f_{TH}^{1/2}$$

Room Temp
Copper at $f_{TH} \sim 100 \text{ MHz}$

$R_{surf} \sim \text{milli-Ohm}$

Superconducting Niobium

Ref. Wangler

$$R_{surf} = 9 \times 10^{-5} \frac{\mu_0^2 (6 \text{ Hz})}{T(0 \text{ K})} \exp\left(-2 \frac{T_c}{T}\right) R + R_{residual}$$

BCS Theory

Material Imperfections

$$\kappa = 1.92$$

$$T_c = 9.2 \text{ K}$$

Critical Temp. (Niobium)

$$R_{residual} = R_{residual} \sim 10^{-9} - 10^{-8} \Omega$$

typical

* Supercond perfect at DC but has AC resistance due to moving Cooper Pairs

$R_{surf} \propto f_{TH}^2$ for high freqs

$$R_{surf} \sim 10^{-5} \times (R_{surf} \text{ Copper})$$

Typical

Dramatic reduction, but SRF materials expensive and fragile + cryogenic cooling is costly.

Quality Factor

Define in full generality (any cavity):

$$\text{Quality Factor} = Q = 2\pi \frac{U}{\langle P_{\text{loss}} \rangle_{\text{1 cycle}}} = 2\pi \times \frac{\text{Energy Stored}}{\text{Energy Dissipated in RF Cycle}}$$

$$Q = \frac{2\pi U}{\langle P_{\text{loss}} \rangle_{\text{1 cycle}}} = \frac{\omega U}{\langle P_{\text{loss}} \rangle_{\text{1 cycle}}}$$

$$Q = \frac{\omega U}{\langle P_{\text{loss}} \rangle_{\text{1 cycle}}}$$

Pillbox Cavity Q

Using previous results for pillbox cavity

$$Q = \omega \left[\frac{\epsilon_0 E_0^2 \pi r_c^2 l}{2} [J_1(x_{01})]^2 \right] \frac{1}{\left[\frac{\mu_0 c}{2 R_{\text{surf}}} \left(\frac{E_0}{\rho_0 c} \right)^2 [J_1(x_{01})]^2 \right]} \approx \frac{U}{\langle P_{\text{loss}} \rangle_{\text{1 cycle}}}$$

$$= \omega \frac{(\epsilon_0 \rho_0 c^2) \mu_0 r_c^2 l}{2 R_{\text{surf}} r_c (r_c + l)}$$

$$= \frac{\omega}{c} \frac{c \mu_0 r_c l}{2 R_{\text{surf}} r_c + l}$$

$$Q = \frac{x_{01} \sqrt{\mu_0 \epsilon_0}}{2 R_{\text{surf}}} \frac{1}{1 + r_c/l}$$

Pillbox Cavity

But at resonant frequency

$$\frac{\omega}{c} = \frac{x_{01}}{r_c} \quad x_{01} \approx 2.405$$

$$c^2 = \frac{1}{\mu_0 \epsilon_0}$$

$$\approx 1.203 \sqrt{\frac{\rho_0}{\epsilon_0}} \frac{1}{R_{\text{surf}}} \frac{1}{1 + r_c/l}$$

Numerically

Want very high Q for cavity

$\Rightarrow R_s$ low : good conductor or superconductor

NC Example: DESY DORIS pillbox Cu cavity

SC Example: FRIB Quarter Wave SRF Cavity

$$Q \approx 38,000 \sim 10^5 @ 500 \text{ MHz}$$

$$Q \sim 10^9 - 10^{10} \text{ range.}$$

High Q corresponds to:

- ★ Low heat generation
- ★ High efficiency
- ★ High stability

: to variations in RF drive and beam loading

To understand the stability point, suppose an isolated cavity has stored energy U in oscillatory mode with angular frequency ω . If the drive is removed $1/4$ the energy U will change as:

$$\frac{dU}{dt} = -\frac{\langle P_{loss} \rangle_{Tf}}{Q} = -\frac{\omega U}{Q} \quad \text{since } Q \equiv \frac{\omega U}{\langle P_{loss} \rangle_{Tf}}$$

This has solution:

$$U(t) = U_0 \cdot e^{-\omega t / Q} \Rightarrow \text{slow decay for } Q \text{ large, giving good stability.}$$

A commonly used Figure of merit of an RF acceleration system is the so-called shunt impedance See Wangler Sec. 2.65

$$V_0 = E_0 L = \text{Effective cavity voltage}$$

Shunt Impedance: $R_S \equiv \frac{V_0^2}{\langle P_{loss} \rangle_{Tf}}$

Note Ohm's Law: $V = IR$
 $P = VI = \frac{V^2}{R} \Rightarrow R = \frac{V^2}{P}$

Caution: Sometimes defined as $R_S = \frac{V_0^2}{2 \langle P_{loss} \rangle_{Tf}}$ (Beaware factor of 2!) due to interpretation of harmonic averaging factors.

Large shunt impedance \Rightarrow Large accelerating potential relative to cavity dissipation, for economical acceleration.

But due to transit time factor, the accel potential V_0 is not fully imparted to particles. Therefore, define an "effective shunt impedance" to take this into account using synchronous phase $\phi_s = 0$ (Max accel.)

$$\Delta W = q(E_0 L) T \cos \phi_s \quad \text{Panofsky Equation}$$

$$\Rightarrow \Delta W_{\text{Max}} = q V_0 T$$

$$E_0 L \Rightarrow E_0 L T$$

$$V_0 \Rightarrow V_0 T$$

In previous formulas for effective measures.

Effective Shunt Impedance

$$R_{\text{seff}} = \frac{(V_0 T)^2}{\langle P_{\text{loss}} \rangle A} = \left(\frac{V_0}{\langle P_{\text{loss}} \rangle A} \right)^2 T^2 = R_s T^2$$

Sometimes these are analyzed per axial length L for long systems:

$$\frac{R_{\text{seff}}}{L} = \frac{E_0^2 T^2}{L \langle P_{\text{loss}} \rangle A} = \frac{(E_0 T)^2}{\langle P_{\text{loss}} \rangle A / L}$$

Typically given in MR/meter

Another figure of merit is "R over Q":

$$R_{\text{over}} = \frac{R}{Q} = \frac{R_{\text{seff}}}{Q} = \frac{(V_0 T)^2}{\langle P_{\text{loss}} \rangle A \omega U} = \frac{(V_0 T)^2}{\omega U}$$

- ★ Measures efficiency acceleration per unit stored energy at specific frequency RF
- ★ Function only of cavity geometry, - Independent of surface properties of power loss.

Energy imparted to beam particles must also come from RF cavity fields.

Instantaneous Power Delivered by Beam

$$P_B = (\# \text{ Particles}) \cdot \Delta W = \frac{I_{\text{beam}}(t) \Delta W}{Q}$$

I_{beam} = beam electrical current, (instantaneous)

The total average power delivered will be

$$\langle P_{\text{Total}} \rangle_{\text{RF}} = \langle P_{\text{Loss}} \rangle_{\text{RF}} + \langle P_B \rangle_{\text{RF}}$$

Take

$$\langle P_B \rangle_{\text{RF}} = \frac{\langle I_{\text{beam}} \rangle_{\text{RF}} \Delta W}{Q}$$

$$Q_{\text{fill}} = \frac{\text{Bucket Fill-Factor}}$$

$$\langle I_{\text{beam}} \rangle_{\text{RF}} = \frac{Q_{\text{bunch}}}{T_{\text{RF}}}$$

$$Q_{\text{bunch}} / Q = N_{\text{bunch}} = \# \text{ particles in bunch}$$

$Q_{\text{fill}} =$ Bucket fill fraction in machine pulse



$Q_{\text{fill}} = 1$ All buckets filled (every RF period)



$Q_{\text{fill}} = 1/2$ Half buckets filled (every other RF period)

$$\langle P_{\text{Total}} \rangle_{\text{RF}} = \langle P_{\text{Loss}} \rangle_{\text{RF}} + Q_{\text{fill}} \frac{N_{\text{bunch}} \cdot \Delta W}{T_{\text{RF}}}$$

* $Q_{\text{fill}} < 1$ occurs when transitioning to higher frequency structures.

The efficiency of the accelerating structure can be

$$\eta = \frac{\langle P_B \rangle_A}{\langle P_{\text{Total}} \rangle_A}$$

Efficiency

For "wall-plug" efficiency must account for other losses:

- * RF Generation
- * Focusing + Bending magnet dissipation
- * Front end
- * Cryo-Plant efficiencies for ^{any} superconducting systems

More efficient accelerators opens the door for more applications:

- * Material processing
- * Energy Production: Subcritical reactors, Actinide Burning, Fusion drivers
- ⋮


Generally want more beam current for high efficiency and this can make/accelerator physics much more difficult due to beam space-charge effects, cavity loading, etc.

- * Much room for future improvements to enable more applications.


Equivalent Circuit for RF Cavity

Motivated by the qualitative correspondence to circuit parameters for the RF cavity the response of the system is idealized in terms of an equivalent circuit.

Equivalent Circuit



(a)




(b)

Wagner

Figure 5.3 (a) Block diagram of RF system components and (b) the equivalent circuit.

Cavity Component (idealized)



Wagner

$$V(t) \Rightarrow \text{Cavity Voltage} \sim E_0 L$$

$$L = \text{Cavity Inductance}$$

$$R = \text{Cavity Resistance}$$

$$C = \text{Cavity Capacitance}$$

Current Conservation / Kirchhoff's Law


$$I(t) = I_L + I_R + I_C$$

$$= \int v dt + \frac{V}{R} + C \frac{dV}{dt}$$

$$I = \frac{V}{L} + \frac{V}{R} + C \dot{V}$$

$$V(t) = \text{RF Cavity Voltage} \sim E_0 \cdot L$$

Recall:



$$V = IR$$

$$I = C \frac{dV}{dt}$$

$$V = L \frac{dI}{dt}$$

Driving current $I(t)$ produces voltage $V(t)$

$V(t) \stackrel{\text{fast}}{\sim} V_0 e^{i\omega t}$ \Leftrightarrow Axial accelerating voltage $V = E_0 L$ of cavity.
with harmonic variation. *No Transit time factor ... cavity only.
 $\frac{1}{2} \epsilon_0 V_0^2 = U \Leftrightarrow$ Energy U stored in the cavity. Sets capacitance C
 $\langle P_{\text{loss}} \rangle_{\text{th}} = \frac{1}{2} \frac{V_0^2}{R} \Leftrightarrow$ Power lost in cavity. Sets resistance R

Express equation as: $I = \frac{V}{R} + \dot{Q} + eV$ as:

$$V + \frac{1}{RC} \dot{V} + \frac{1}{LC} V = \frac{I}{C} \stackrel{\text{Drive}}{\uparrow}$$

Express as:

$$\ddot{V} + \frac{\omega_{\text{res}}}{Q} \dot{V} + \omega_{\text{res}}^2 V = \frac{I}{C}$$

$\omega_{\text{res}} = \frac{1}{\sqrt{LC}}$ = Resonant Freq \Leftrightarrow Set L to get correct angular freq. 1)

Motivated from prev damping analysis: 15 Feb.

$$\frac{1}{RC} = \frac{\omega_{\text{res}}}{Q} = \frac{1}{RC} Q \Rightarrow Q = R\sqrt{\frac{C}{L}} = \omega_{\text{res}} \frac{U}{\langle P_{\text{loss}} \rangle_{\text{th}}} = \omega_{\text{res}} RC$$

$Q = \omega_{\text{res}} \frac{U}{\langle P_{\text{loss}} \rangle_{\text{th}}} = \omega_{\text{res}} RC \Leftrightarrow$ Set R to get correct damping 2)

Reminder:

$U = \frac{1}{2} \epsilon_0 V_0^2 \Leftrightarrow$ set C to get correct stored energy 3)

1), 2), 3) to fix circuit params

Search for a harmonic steady-state solution ($t \rightarrow \infty$) of circuit.

$$I(t) = I_0 e^{i\omega t}$$

$\omega = \text{const}$ angular freq. (need not satisfy $\omega = \omega_{res}$)
 $I_0 = \text{const}$

Analysis shows that (electrical engineering texts)

$$V(t) = \frac{R I_0 e^{i(\omega t + \phi)}}{\sqrt{1 + Q^2 \left(\frac{\omega}{\omega_{res}} - \frac{\omega_{res}}{\omega} \right)^2}}$$

$$\phi = -\tan^{-1} \left[Q \left(\frac{\omega}{\omega_{res}} - \frac{\omega_{res}}{\omega} \right) \right]$$

Denote

$$\Delta\omega = \omega - \omega_{res}$$


Then

$$Q \left[\frac{\omega}{\omega_{res}} - \frac{\omega_{res}}{\omega} \right] = Q \left[1 + \frac{\Delta\omega}{\omega_{res}} - \frac{1}{1 + \frac{\Delta\omega}{\omega_{res}}} \right] \approx 2Q \frac{\Delta\omega}{\omega_{res}}$$

The frequency shift $\Delta\omega$ to reduce the voltage amplitude to $1/\sqrt{2}$ the value (i.e., the 1/2 power value) on resonance is:

$$V_{res}(t) = V(t) \Big|_{\substack{\omega = \omega_{res} \\ \Delta\omega = 0}} = R I_0 e^{i\omega t} = V(\omega) e^{i\omega t}$$

$$V(t) \Big|_{\omega = \omega_{res} + \Delta\omega} = \frac{R I_0 e^{i\omega t}}{\sqrt{1 + 4Q^2 \frac{\Delta\omega^2}{\omega_{res}^2}}} = V(\omega) e^{i\omega t} \cdot \text{Phase}$$



for $4Q^2 \frac{\Delta\omega^2}{\omega_{res}^2} = 1 \Rightarrow \Delta\omega = \frac{\omega_{res}}{2Q}$

High Q means very sharply tuned resonant frequency.

Frequency Scaling in RF Cavity figures of Merit

Wangler 2.7

One of the most important parameters to choose in design is the cavity frequency f_{rf}

$$\omega = \frac{2\pi}{T_{rf}} = 2\pi f_{rf}$$

Take:

$E_0 = \text{const}$
 $\Delta W = \text{const}$ } Fixed independent of f_{rf} and fix length L

scale all other cavity dimensions with RF wavelength $\lambda_{rf} = \frac{c}{f_{rf}}$
 Then (regard energy gain fixed so)

Transit Time T independent of f_{rf}

Cavity surface Area $\sim r_c \sim \frac{1}{f_{rf}}$

Cavity Volume $\sim r_c^2 \sim \frac{1}{f_{rf}^2}$

Surface Resistance

$R_{surf} \sim \begin{cases} f_{rf}^{1/2} & \text{Normal Cond (NC)} \\ f_{rf}^2 & \text{Superconducting (SC)} \end{cases}$

\sim Skin depth scaling
 \sim Neglect residual Resistance (good approx f_{rf})

Avg. Power Loss $\langle P_{loss} \rangle_{rf} \sim R_{surf} |B|^2 \cdot S \sim \begin{cases} f_{rf}^{1/2} & \text{NC} \\ f_{rf}^2 & \text{SC} \end{cases}$

Quality Factor $Q = \frac{\omega W}{\langle P_{loss} \rangle_{rf}} \sim \begin{cases} f_{rf}^{1/2} & \text{NC} \\ f_{rf}^{-2} & \text{SC} \end{cases}$

Effective Shunt "Impedance"

$$R_{seff} = \frac{(V_o T)^2}{\langle P_{loss} \rangle_{RF}} \sim \frac{1}{\langle P_{loss} \rangle_{RF}} \sim \begin{cases} f_{rf}^{1/2} & NC \\ f_{rf}^{-1} & SC \end{cases}$$

★ Effective shunt impedance per unit axial length scales the same as R_{seff} .

$$\frac{R}{Q} \equiv \frac{R_{seff}}{Q} \sim \frac{(V_o T)^2 \langle P_{loss} \rangle_{RF}}{\langle P_{loss} \rangle_{RF} \omega U} \sim \frac{1}{\omega U} \sim \begin{cases} f_{rf} & NC \\ f_{rf} & SC \end{cases}$$

R over Q

★ R over Q scales same for NC and SC since it should be independent of surface properties.

$$\sim \frac{3\pi \tan(\phi_s) \sqrt{\epsilon_0 \epsilon_s} \Delta A (S_m(\phi_s) - \phi_{res} \phi_s)}{2 \epsilon_0 \epsilon_s \Delta A} \sim f_{rf}^{-1/2}$$

Phase-space Area Bucket that can be accelerated


★ Higher frequency will lead to lower longitudinal "acceptance" for phase space area that can be accelerated by bucket.

- "Matching" important too if frequency transitions.

Comment: If linac has frequency transitions only harmonics and sub-harmonics are possible for a wave train of RF buckets. In certain cases only a limited fraction of buckets will be filled.


RF Bunch Structures

All Buckets Filled Continuous Wave




- * Highest intensity on target
- * Max use of RF
- * Ideal for cyclotrons, high power RF / masers, etc.

50% Buckets Filled Continuous Wave



- * Skip any # buckets to reduce intensity on target.

2. Micropulses With all Buckets Filled



- * Trains of bunches for consistency with sources etc.

o + Many Variants.
o
o
o
o

Many reasons for various micro-pulse structures,

- * RF Structure limits in Power (more idle time)
- * Source limitations of particles
- * Frequency changes: transitions to higher frequencies for more compact structures.
- * Target limitations
- * Machine fill cycles of circular machines

Mod on Cavities

RF Cavities very diverse topic. Can teach whole course on just aspects of technology.

Beam tube on pillbox cavity adds complication:

- * Want field concentrated on gap for larger transit-time factor.
- * Opening large enough to get beam in and out of cavity \Rightarrow Ef generated.
- * Peak E may no longer be on-axis.

SC Cavities
 High Epeak \Rightarrow Field emission e⁻'s, decreased efficiency + damage possible

NC Cavities
 High Epeak \Rightarrow Electric Breakdown, Cavity damage + loss of Eacc

Eacc = Accelerating E-field

Epeak $\sim 2-3 \times Eacc$

Figure of Merit = $\frac{Epeak}{Eacc}$

- * Resonant cavity angular freq ω more sensitive to cavity dimensions.
- * Large Bo on outer walls of cavity can quench if superconducting critical magnetic field exceeded. The critical field depends on temperature.

Bcritical ~ 0.2 Tesla for 2-420K Niobium

Impurities reduce:

BMax ~ 0.1 Tesla typical for operation.

For pill box cavity $\frac{C_{Bmax}}{E_{max}} = \frac{C_{Bmax}}{E_{acc}} = 0.5819$

but this value can increase on drift-tubes, nose cones, etc.
 Elliptical cavities shaped to reduce Bo at outer walls.

Electron Field Emission Limits SC Cavity E_{max} ; Wangler 5.10

e^- emitted from surface in strong E field. \Rightarrow strike cavity after gaining energy and generate heat + X-rays when stopping.
Lowers Q

Fowler-Nordheim Law:

$$\text{Current Density} \propto \frac{E_{peak}}{\Phi} \exp\left(-\frac{a\Phi^{3/2}}{E_{peak}}\right)$$

Φ = work function
 $\approx 4.3\text{eV}$ for Niobium
 E_{peak} = Peak electric field on surface.
 $a = \text{const.}$

$$E_{peak} \sim 250 \times (E_{max} \text{ of cavity on surface})$$

Due to surface roughness.

Very important for superconducting surfaces to be clean and smooth.

RF Electric Breakdown Limits NC Cavity E_{max} ; Wangler 5.11

It is found empirically by Kilpatrick (Rev. Sci. Inst.) 28, 824 (1957).

* for a given freq for the peak E field on the surface before breakdown given by

$$f_{\#}(\text{MHz}) = 1.64 E_{max}^2 \sim 2.5 E_{max} \quad \Rightarrow \text{Plot}$$

E_{max} in MV/m

* Somewhat conservative, often take

$E_{max} = B (E_{max} \text{ from Kilpatrick})$
 $B = \text{"bravery factor" } 1-2 \text{ typical}$




Figure 5.14 Kilpatrick formula from Eq. 5.801. *

Idealized Pillbox cavity is distorted to better optimize.

MIT Translate circuit model to a cavity model:
 Directly driven, re-entrant RF cavity

Outer region: Large, single turn inductor
 $L = \frac{\mu_0 \pi a^2}{2\pi(R+a)}$



Central region: Large plate capacitor
 $C = \epsilon_0 \frac{\pi R^2}{d}$

$$\omega_0 = \frac{1}{\sqrt{LC}} = c \left[\frac{2(R+a)d}{\pi R^2 a^2} \right]^{1/2}$$

Q - set by resistance in outer region
 $Q = \sqrt{L/C} / R$

Source: Humphries, Charged Particle Accelerators

Bartlett
 US PARTICLE ACCELERATOR SCHOOL




Elliptical Cavity

- want:
- Small gap d for efficient acceleration
 - Transit time factor T large
 - Raise effective shunt impedance R_{sh}
 - Expand outer region, raises Q
 - Distribute B_0 and reduce intensity for given V_0, d .


$E_{acc} \sim V_0$
 $U = \frac{1}{2} C V_0^2$
 $\langle P_{loss} \rangle = \frac{1}{2} V_0 / R$
 $\omega_{res} = \frac{1}{\sqrt{LC}}$
 $Q = \omega_{res} \frac{U}{\langle P_{loss} \rangle}$

Coupled Cavities Groups of adjacent RF cavities are coupled together to maintain relative RF Phase control

- * Common for high β particle acceleration
 - Simplifies RF drive
 - Saves cost
 - Many possible geometries
- * Coupling can be through beam apertures or slots, or sometimes special coupling cavities
 - Coupling cavities sometimes off axis or minimal length to save space.
- * Usually transverse focusing placed between banks of cavities.




Wille
 Fig. 5.5 Layout of a five-cell accelerating structure. The power feed is coupled to the middle cell and two tuning plungers are sufficient for the entire structure.




Wang for Figure 4.17 Four examples of coupled-cavity linacs.

Elliptical: 5-Cell Bank






Wang for Figure 2.5
 Cross section of a $\beta = 0.82$ elliptical cavity designed for a superconducting proton linac. The cross section for each cell consists of an outer circular arc, an ellipse at the iris, and a connecting straight line.


Phase relations between E-fields in cavities can vary.



Wangler
Figure 12.2 Coupled-cavity drift-tube linac (CCDTL) structure with a single drift tube in each accelerating cavity.



Wangler
Figure 4.11 Side-coupled linac structure as an example of a coupled-cavity linac structure. The cavities on the beam axis are the accelerating cavities. The cavities on the side are normally unexcited and stabilize the accelerating-cavity fields against perturbations from fabrication errors and beam loading.




Wangler
Figure 4.15 pi/2-like-mode operation of a cavity resonator chain. From top to bottom are shown a periodic structure in pi/2 mode, a biperiodic on-axis coupled-cavity structure in pi/2 mode, and a biperiodic side-coupled cavity in pi/2 mode.

Low Frequency Half and Quarter Wave RF Structures

For low freq. ion acceleration with cavities operating with $f \approx 100$ MHz, cavities based on coaxial resonators are employed.

* Used in FRIB. $1/4$ and $1/2$ wave SRF Cavities.

Basic Idea: Half-Wave Structure



Will show on a homework problem that an EM standing wave solution exists with

$1/r$ variation not much over range

$$E_r = -2\sqrt{\frac{\rho_0}{\epsilon_0}} \cdot \frac{I_0}{2\pi r} \sin\left(\frac{\pi r z}{l}\right) \sin(\omega t + \phi)$$

$$B_\theta = \frac{\rho_0 I}{\pi r} \cos\left(\frac{\pi r z}{l}\right) \cos(\omega t + \phi)$$

$$p = 1, 2, 3, \dots$$

$p=1 \Rightarrow$ Half-Wave

$$\omega = \frac{\pi c}{l}$$

$I_0 =$ Amplitude of traveling wave current components on inner conductor.

$$V = \int_{r_i}^{r_o} E_r dr = \text{Accel. Voltage.}$$

- * Beam holes at $z = l/2$ where voltage is maximum
- * Beam moves on radial path sees no field when inside inner conductor (like drift tube).
- * RF phase advances π by the time when traversing the inner conductor so that the particle can be accelerated on both entrance and exit sides.
- * Conductor radii chosen for max energy gain on each side
- * Effectively forms 2 gap cavity. 2ω Transit time factor of HV problems applies.


Will also show in homework problems for the $\lambda/2$ -wave coaxial resonator:

$$U = \frac{\mu_0 I_0^2 \ln(l_0/\pi)}{2\pi} \quad \text{RF Energy Stored}$$

$$Q = \frac{\pi \sqrt{\frac{\mu_0}{\epsilon_0}}}{R_{\text{surf}}} \frac{\ln(l_0/\pi)}{l \left[\frac{1}{\pi} + \frac{1}{l_0} \right] + 4 \ln(l_0/\pi)} \quad \text{Quality Factor}$$

Quarter Wave Structure

Essentially split the half-wave structure divided in two with a capacitive termination at the division point.



* Has a lesser degree of symmetry and fields will be distorted more than in the half-wave resonator.

Design formulas including the contribution to the fields from the capacitive gap termination can be found in

Moreno, Microwave Transmission Design Dts, Dover, NY 1948, pp. 227-230.

Both Quarter and Half-Wave structures produce more compact low freq. cavities:
 * Save RF power
 * Cheaper Superconducting (less material, less losses to cool, ...)

Coupling to RF Cavities


See Wille, "The Physics of Particle Accelerators," Chapter 5
 Wilson, "An Introduction to Particle Accelerators," Chapter 5
 Wangler, "RF Linear Accelerators" Chapter 5

Beyond scope to discuss in this class.
 Many ways to couple RF power to resonant cavities.
 Most common may be with a loop to couple with magnetic field of EM TM₀₁₀ type standing wave.

- * Place where magnetic field high in outer radial extent of cavity
- * Field created by loop should have component in common with B₀ of TM₀₁₀ type mode (or whatever mode) desired to excite.

Coupling of klystron to waveguide + coaxial cable also an issue. Much to consider.

Magnetic Coupling Loop at end of Coaxial Transmission Cable



Wille
 Fig. 5.4 Design of a single-cell accelerating structure using the TM₀₁₀ mode. The exact resonant frequency is adjusted using a tuning plunger. The resonator is excited by an inductive coupling loop.




Fig. 10.15 Two examples of loop coupling.
 Wilson

TM₀₁₀ type mode

Common Methods Coupling.

- 1) Magnetic Loop at end of coaxial transmission line connected to cavity
- 2) Hole or Aperture in cavity wall connected to a wave guide
- 3) Electric Coupling Probe or Antennas using the central conductor of a coaxial transmission line.




Figure 5.2 Methods of coupling to cavities.

Comments:

- * Want structure using low order mode to make easy modes, to excite and avoid coupling to higher order modes.
 - Preclude coupling to higher order modes by frequency choice.
- * Couplers have much difficult engineering
 - Heat leak for SRF structures.


RF Sources

See Wille, "The Physics of Particle Accelerators" Chapter 5
 Wilson, "An Introduction to Particle Accelerators" Chapter 5


Harmonically varying RF power needed for accelerating structures ranging from a few kW to MW power levels. Pulses may be short, long, or continuous wave (CW).

- 1) Triode / Tetrode: few MHz \rightarrow few 100 MHz ; high power broad band
 - 2) klystron: few 100 MHz +
 - 3) Also: Traveling Wave Tubes, Magnetrans, Cross-Field Amplifiers, Gyrotrons,
- Klystron

Drift long enough to bunch
 using TM_{010} or TM_{012}



Wille Fig. 5.11 The classical microwave klystron, operating in the ten centimetre region.



Wille Fig. 5.4 Design of a single-cell accelerating structure using the TM_{010} mode. The exact resonant frequency is adjusted using a tuning plunger. The resonator is excited by an inductive coupling loop.

Power delivered by klystron

e^- beam source large:

$I_{beam} \sim 10 A$ typical

$V \sim 10^5$ kV Source Voltage typical.

$$P_{Klystron} = \eta V I_{beam}$$

~ 1.2 MW

per tube now achieved in CW operation.
@ 350 - 500 MHz

~ 250 kW typical CW values.

Real klystrons may use several resonators to extract more energy and increase efficiency.
Many variants including relativistic klystrons using higher (MeV) energy e^- beams.

$\eta = \text{Efficiency}$ 45% \rightarrow 65% typical

99/

* Numerous topics on RF cavity design, SRF specific issues, RF sources, couplers, cavity measurements, and engineering issues.

* Many texts exist on topic. Often older books and manuscripts.

* USPAS classes cover specifics.

- Microwave Measurements Laboratory
- RF Power Engineering
- Applied Electromagnetism; Magnet & Cavity Design
- Two SRF classes.

- Microwave Sources vs

- RF Linear Accelerators

o
o
o

* Many additional important topics not covered.

- Microwave coupling to cavities and waveguides
- Slater perturbation theorem
 - Basis of bead pull of small metallic structures to measure cavity frequency
 - Tuning RF cavities via mechanical deformation.

o
o
o