


Momentum Compaction

The path length that a particle travels in a lattice between reference orbit coordinates s_1 and s_2 will vary with particle momentum p .

$$L = \int_{s_1}^{s_2} \sqrt{\underbrace{\left(1 + \frac{x}{\rho}\right)^2}_{\substack{\uparrow \\ \text{due to} \\ \text{bend}}} + \underbrace{x'^2 + y'^2}_{\substack{\uparrow \\ \text{from particle} \\ \text{offset}}} ds$$



Expand for small orbit angles (paraxial approximation)

$$L \approx \int_{s_1}^{s_2} \left(1 + \frac{x}{\rho}\right) ds$$

Neglect the relatively small contribution to x from betatron motion, but account for the larger contribution due to dispersive effects from off momentum then:

Essentially measures shift in x of orbit center with δ .

$$x \approx D(s) \frac{\delta p}{p_0} = D(s) \delta$$

$$L \approx \int_{s_1}^{s_2} ds + \delta \int_{s_1}^{s_2} \frac{D(s)}{\rho(s)} ds$$

$$L_0 \equiv \int_{s_1}^{s_2} ds = \text{Reference orbit path length}$$

$$= s_2 - s_1$$

$$L \approx L_0 + \delta \int_{s_1}^{s_2} \frac{D(s)}{\rho(s)} ds$$

Denote

$\Delta L = L - L_0 =$ change in path length due to off-momentum δ .

$$\Rightarrow \Delta L = \delta \int_{s_1}^{s_2} \frac{D(s)}{p(s)} ds$$

Define the momentum compaction factor α_c by

$$\frac{\Delta L}{L_0} \equiv \alpha_c \frac{\delta p}{p_0} \quad \alpha_c \equiv \frac{\int_{s_1}^{s_2} \frac{D(s)}{p(s)} ds}{\int_{s_1}^{s_2} ds} = \text{Momentum "Compaction" factor}$$

- * α_c is average of D/p over ideal (reference) path.
- * α_c is a property of the lattice.
- * For a ring, typical to take path over full ring lap reference path.

$$\alpha_c = \frac{\oint_{\text{ring}} \frac{D(s)}{p(s)} ds}{\oint_{\text{ring}} ds}$$

In this context, we define (will become clear soon why we do this)

$$\alpha_c \equiv \frac{1}{\gamma_t^2} \quad \gamma_t \equiv \text{Transition gamma.}$$

For simple lattices: $\gamma_t \approx$ number betatron oscillations in ring.

See SY Lee pg 121

To prepare for needs to analyze longitudinal phase-focusing in RF cavities in rings. (we will cover later), need to also analyze the time it takes for a particle to travel along the path of length L.

$$T = \frac{L}{c\beta} = \text{Transit time, (assume no accel).}$$

$\beta = \frac{v}{c}$ not to be confused with c.s. betatron function.

$$\ln T = \ln \frac{L}{c\beta}$$

$$\Rightarrow \frac{\Delta T}{T_0} = \frac{\Delta L}{L_0} - \frac{\Delta \beta}{\beta_0}$$

$$\frac{\Delta L}{L_0} \equiv d_c \frac{\delta p}{p_0}$$

subscript "0" denotes reference

need to calculate $\frac{\Delta \beta}{\beta_0}$ in terms of $\frac{\delta p}{p}$ to calculate $\frac{\Delta T}{T_0}$ in terms of $\frac{\delta p}{p}$.

Examine:

Expressions also true for reference particle (subscript 0)

Total Energy $E \equiv \gamma m c^2$
Momentum $p = \gamma m \beta c$

$$\Rightarrow c p = \beta (\gamma m c^2) = \beta E \Rightarrow \frac{\delta p}{p_0} = \frac{\Delta \beta}{\beta_0} + \frac{\Delta E}{E_0}$$

Here we use Δ for differentials to avoid confusion with $\delta \equiv \frac{\delta p}{p}$

$$E^2 = c^2 p^2 + m^2 c^4 \Rightarrow \Delta E E = c^2 p \delta p \rightarrow \frac{\Delta E}{E_0} = \frac{c^2 p_0 \delta p}{E_0^2} = \frac{c(c p_0)}{E_0^2} \delta p = \frac{c \beta_0 E_0}{E_0^2} \delta p = \frac{c \beta_0 \delta p}{E_0} = \frac{c \beta_0}{c \beta_0 / \beta} \frac{\delta p}{p} = \beta^2 \frac{\delta p}{p}$$

Thus

$$\frac{\Delta \beta}{\beta_0} = \frac{\delta p}{p_0} - \frac{\Delta E}{E_0} = (1 - \beta_0^2) \frac{\delta p}{p} = \frac{1}{\gamma_0^2} \frac{\delta p}{p}$$

$$\frac{\Delta \beta}{\beta_0} = \frac{1}{\gamma_0^2} \frac{\delta p}{p}$$

Using these results,

$$\begin{aligned}\frac{\Delta \mathcal{P}}{\mathcal{P}_0} &= \frac{\Delta L}{L_0} - \frac{\Delta \beta}{\beta_0} \\ &= dc \frac{d\mathcal{P}}{\mathcal{P}_0} - \frac{1}{\gamma_0^2} \frac{d\mathcal{P}}{\mathcal{P}_0} = \left(dc - \frac{1}{\gamma_0^2} \right) \frac{d\mathcal{P}}{\mathcal{P}_0}\end{aligned}$$

Define:

$$\eta_s = \frac{1}{\gamma_0^2} - dc = \text{"Slip Factor"}$$

Then,

$$\frac{\Delta \mathcal{P}}{\mathcal{P}_0} = -\eta_s \cdot \frac{d\mathcal{P}}{\mathcal{P}_0}$$

Notice that at $\gamma_0 = \gamma_t = \frac{1}{\sqrt{dc}}$ $\eta_s = 0$
corresponding to the "transition energy" of a ring.

The formula for $\Delta T/T$ is important when examining conditions to maintain synchronism with RF cavities in a ring.

Denote:

$$\omega_r = \text{Angular frequency to complete revolution in ring} = \frac{2\pi}{T_r}$$

T_r = revolution period in ring

T_{r0} = design revolution period in ring

Then

$$\Delta\omega_r = \frac{-2\pi \Delta T_r}{T_{r0}^2} \Rightarrow \frac{\Delta\omega_r}{\omega_{r0}} = \frac{-\Delta T_r}{T_{r0}} = \eta_s \frac{\delta p}{p_0}$$

$$\frac{\Delta T_r}{T_{r0}} = -\frac{\Delta\omega_r}{\omega_{r0}} = -\eta_s \frac{\delta p}{p_0}$$


<u>Case</u>	<u>Particle Energy</u>	<u>Slip Factor</u>	<u>Consequence</u>
$\gamma > \gamma_t \Leftrightarrow$	Above Transition \Leftrightarrow	$\eta_s < 0$	high momentum particle takes <u>longer</u> time to make lap.
$\gamma < \gamma_t \Leftrightarrow$	Below Transition \Leftrightarrow	$\eta_s > 0$	high momentum particle takes <u>shorter</u> time to make lap.

∴ RF cavity phase control in a ring is different above and below transition energy.

* Not surprising: Going through transition in an acceleration cycle can be a problem!

- When $\gamma = \gamma_t$ $\eta_s = 0$ does not really imply $\frac{\Delta T_r}{\Delta T_{r0}} = 0$. Higher order terms will matter in this case and analysis will be more difficult.

For a ring, conceptually:



Momentum deviation
makes path length
deviation.

We will take this into
account using

$$\frac{\Delta T_r}{T_{r0}} = -\eta_s \frac{\delta p}{p_0}$$

When studying RF acceleration
in a ring,

Note $\eta_s = \frac{1}{\gamma^2} - \alpha_c$

with α_c a property
of the lattice.